

### **Product Information ZMU-PT**

**CONTROLS** 

### Temperature Controller ZMU-PT

### Application / specified usage

• The temperature controller ZMU-PT converts the signal from a Pt100 into a linearized standard signal 0...10 V or 0/4...20 mA, proportional to the temperature.


# Labeling

### **Features**

- · 3 or 4 wire connection for Pt100 input (selectable)
- · Zero and gain freely adjustable
- · Measurement range freely adjustable via latches and trimmer
- · Current output (0/4...20 mA) via sliding switch selectable
- · Plug-in terminal connections
- · Extra slim version
- · CE label
- · Least gain range 25 Kelvin



Technical data					
Housing	acc. to DIN norm dimensions	made of ABS for rail mounting acc. to EN 50022 22.5 x 75 x 105 mm (W x H x D)			
Protection class		IP20			
Ambient	storage temperature operating temperature humidity	-20+70 °C -10+55 °C 095 %, no condensation			
Terminals		2.5 mm <sup>2</sup> , screw-type terminals pluggable			
Input		Pt100, 3 or 4 wire selectable (S1)			
Measurement range	freely adjustable	see table "Measurement range adjustment"			
Output	voltage (option) current	010 V 0/420 mA			
Accuracy		≤ ±0.2 %, ±0.3 % max. from measurement range			
Temperature drift		≤ 0.01 % / K			
Power supply		1536 V=, 80 mA max., protected against polarity reversal			
Weight		ca. 150 g			



#### **Trimmers and Selector Switches**

- P1 zero (N), adjusting range -20...+50 °C (no latch N1/N2)
- · P2 gain (V), adjusting range ±30 % (on latch V2)
- · S1 input selector:
  - · position of switch to lid = 3 wire connection
  - position of switch into the interior = 4 wire connection
- · S2 output selector 0...20 mA or 4...20 mA
- N1 zero offset for positive inputs (e.g. +100 °C = 0 mA)

2

- N2 zero offset for negative inputs (e.g. -50 °C = 0 mA)
- · V1 gain increase by factor 2.5 (in relation to V2)
- · V2 normal gain
- · V3 gain decrease by factor 2.5 (in relation to V2)

### **Adjustment**

- Use switch S1 to select the desired input type (3 wire/4 wire) and use S2 to select current output (0...20/4...20 mA).
- 2. Set converter to desired input range as per table.
- 3. Connect Pt100 simulator (e.g. HSM-P) to input (pins 1-4, see connection diagram).
- Loop ammeter (range 20 mA DC) in current output line or shunt voltmeter (range 10 V=) to voltage output of the device.
- 5. Apply supply voltage (pins 5/6).
- Apply zero signal to input (lower measuring range value e.g. 0 °C).
- 7. Use trimmer P1 (N) to set output to 0 mA (4 mA on output 4...20 mA) or 0 V respectively.
- 8. Apply max. input signal (upper range value e.g. 100 °C).
- Use trimmer P2 (V) to set output signal to 20 mA or 10 V respectively.
- 10. Check intermediate values.

Table measurement range adjustment							
Input range	Latching switches						
	N1	N2	V1	V2	V3		
025 °C up to 050 °C (V 2550 K)	-	-	х	-	-		
050 °C up to 0120 °C (V 50120 K)	-	-	-	Х	-		
0120 °C up to 0300 °C (V 120300 K)	-	-	-	-	Х		
0300 °C up to 0600 °C (V 300600 K)	-	-	-	-	-		
zero < -30 °C	-	Х					
zero > +30 °C	Х	-					

- = Latching switch open
- x = Latching switch closed

## **Block diagram** Pt100 3 or 4 wire analog input of PLC 0-20mA output $1^{1}$ 8 4 S1

### Installation advice

3



· For installation and adjustment please pay attention to additional informations given in the data sheet enclosed with the device.

### Conventional usage



- · Not suitable for applications in explosive areas.
- · Not suitable for applications in security-relevant equipments (SIL).

### Transport/storage



- · No outdoor storage
- · Dry and dust free
- · Not exposed to corrosive media

+ 24V -

- · Protected against solar radiation
- · Avoiding mechanical shock and vibration
- · Storage temperature -20...+70 °C
- · Relative humidity max. 95 %

### Reshipment

Standards and guidelines



 Use suitable transport packaging only to avoid damage of the equipment!

### **Note on CE**



- · Applicable directives:
  - · Electromagnetic Compatibility Directive 2014/30/EU
  - · Low Voltage Directive 2014/35/EU
- · Compliance with the applicable EU directives is identified by the CE label on the product.
- · The operating company is responsible for complying with the guidelines applicable to the entire installation.
- · The measuring line to Pt100 must be shielded. Connect the shielding to pin 1 (see figure).
- · If strong EMI ambient is expected useage of a folding ferrite at the supply line is appropriate (e.g. type 742 712 21 from Würth).

### Disposal

directives.



· Electrical devices should not be disposed of with household trash. They must be recycled in accordance with national laws and regulations.

· You have to comply with applicable regulations and

· Take the device directly to a specialized recycling company and do not use municipal collection points.



